



HTC Thunderbolt Battery Replacement

Written By: Brandon Younger



INTRODUCTION

Use this guide to replace the battery in the HTC Thunderbolt.



TOOLS:

- [iFixit Opening Tools](#) (1)
-

Step 1 — Rear Panel



- Insert the plastic opening tool into the top of the Thunderbolt near the power button.
- Gently pry up on the rear panel around the edges until it is loose.

Step 2



- Lift and remove the rear panel.

Step 3 — Battery



- Using the plastic opening tool, lift up the battery from the bottom near the kickstand.
- Remove the battery from the inner frame.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 11:04:41 AM.